

FR500S Corner Light Brake Duct

The following pictures illustrate how to modify the front corner lights on a FR500S for use as an additional brake cooling duct. The lens is trimmed to allow air into the light, and the bulb holder is removed to allow a 2" duct to be attached. The duct is attached by drilling two small holes and using safety wire.







