



**M-9430-V302
Street Rod Headers
INSTALLATION INSTRUCTIONS**

NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD RACING PERFORMANCE PARTS.

Please visit www.fordracingparts.com for the most current instruction information

**!!! PLEASE READ ALL OF THE FOLLOWING INSTRUCTIONS CAREFULLY PRIOR TO INSTALLATION.
AT ANY TIME YOU DO NOT UNDERSTAND THE INSTRUCTIONS, PLEASE CALL THE FORD RACING
TECHLINE AT 1-800-367-3788 !!!**

INSTALLATION TIPS FOR STREET ROD HEADERS:

Our street rod headers have been designed to fit a wide variety of chassis. The compact arrangement of these headers will require the use of a small, factory type engine mount. Part numbers 207-2220 (passenger's side) and 270-2221 (driver's side) engine mounts, from Sealed Power work with only minor modifications. These engine mounts feature a single stud to attach to your frame brackets. Sealed Power parts are available from your local auto parts outlet.

The driver's side engine mount may have to be trimmed for acceptable fit. We recommend at least 1/4" clearance between the mount and the header.

Due to space limitations, we recommend the use of the hi-torque mini starter; part number M-11000-A50.

Factory Ford shop manuals are available from Helm Publications, 1-800-782-4356