

NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS © Ford Motor Company 2020

### PRIOR TO INSTALLATION READ THESE INSTRUCTION COMPETELY For questions, Call the FORD PERFORMANCE Techline 1-800-367-3788

Please visit <a href="https://www.performanceparts.ford.com">https://www.performanceparts.ford.com</a> for warranty information

#### **OVERVIEW:**

A commercial shop hoist is recommended for installation. It is possible to use a hydraulic floor jack and jack stands to raise the vehicle.

Reference the Owner Manual for Jacking Procedures

CAUTION - JACK STANDS MUST BE USED ON A LEVEL SURFACE AND BE SECURELY SEATED TO THE VEHICLE. FAILURE WILL RESULT IN PERSONAL INJURY OR VEHICLE DAMAGE!

#### **KIT INCLUDES:**

<u>Qty:</u>	<u>Description</u>
2 1	Muffler X-Pipe
4	Clamp
1	Left Hand Intermediate Pipe
1	Right Hand Intermediate Pipe
1	Rear Valance
	<u> </u>


Ford Factory Shop Manual purchase options www.motorcraftservice.com

Techline 1-800-367-378 Page 1 of 18 IS M-5200-M4xxBV 031020



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS © Ford Motor Company 2020

#### Image of New Cat Back Exhaust System:




M8SBV/TBV front section shown

Ford Factory Shop Manual purchase options <u>www.motorcraftservice.com</u>

Techline 1-800-367-378 Page 2 of 18 IS M-5200-M4xxBV 031020



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS © Ford Motor Company 2020



Tighten the exhaust clamp.


- The exhaust clamp should be installed so that it is up to, but not over, the bottom of the notches.
- · Tighten to 48 Nm (35 lb-ft).

NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS © Ford Motor Company 2020

#### **INSTALLATION INSTRUCTIONS:**

**STEP 1:** Raise and support vehicle.

STEP 2: Spray penetrate on exhaust coupler bolts. Loosen all Exhaust coupler bolts.



Techline 1-800-367-378 Page 4 of 18 IS M-5200-M4xxBV 031020



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS © Ford Motor Company 2020

STEP 3: Using a 15mm socket loosen nuts on clamps.



STEP 4: Using a 13mm socket remove bolts from exhaust hangers in rear Sub frame.



Ford Factory Shop Manual purchase options <u>www.motorcraftservice.com</u>

Techline 1-800-367-378 Page 5 of 18 IS M-5200-M4xxBV 031020




NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS © Ford Motor Company 2020

STEP 5: After loosening exhaust clamps, slide clamps back on exhaust pipe releasing them from the down pipes. Remove clamps from resonator pipes and slide back onto down pipes.



Step 6: Allowing exhaust to hang down, remove rear mufflers from hangers by moving the exhaust system towards front of vehicle.

Note: Have someone help with this step.



Ford Factory Shop Manual purchase options <u>www.motorcraftservice.com</u>

Techline 1-800-367-378 Page 6 of 18 IS M-5200-M4xxBV 031020



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS © Ford Motor Company 2020

Step 7: Remove factory exhaust clamps from system and slide them onto flex pipes locking the lock tabs in place.



Step 8: Install new x-pipe onto clamps and tighten to 47.5nm (35 lb-ft)



Ford Factory Shop Manual purchase options <u>www.motorcraftservice.com</u>

Techline 1-800-367-378 Page 7 of 18 IS M-5200-M4xxBV 031020



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS © Ford Motor Company 2020

#### Step 9: Install factory removed hangers onto under axle pipes.



### Step 10: Install supplied clamps onto x-pipe side of under axle pipes, slide pipes/clamps onto x-pipe. Using a 13mm socket install bolts in exhaust hangers in rear Sub frame.



Ford Factory Shop Manual purchase options <u>www.motorcraftservice.com</u>

Techline 1-800-367-378 Page 8 of 18 IS M-5200-M4xxBV 031020



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS © Ford Motor Company 2020

Step 11: Using a 13mm socket tighten bolts to 25 nm (18 lb-ft) in rear Sub frame exhaust hangers.



Step 12: Using a 15mm socket tighten nuts on x-pipe clamps 47.5 nm (35 lb-ft)






NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS © Ford Motor Company 2020

#### **Rear Bumper Cover Removal**


#### Step 13: Remove the push pins.



0100100

#### Step 14: NOTE: On both sides.

Disconnect the rear bumper harness electrical connector and separate the wiring harness guide.



0100100

Ford Factory Shop Manual purchase options www.motorcraftservice.com

Techline 1-800-367-378 Page 10 of 18 IS M-5200-M4xxBV 031020




NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS © Ford Motor Company 2020


Step 15: Remove the rear wheels and tires.

Step 16: NOTE: On both sides.

Remove the screw and the pushpins.



Step 17: Remove the bumper cover to bracket screws. (Two on each side) Torque: 13 lb.in (1.5 Nm)



Bumper cover to bracket screws.




NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS © Ford Motor Company 2020

- Step 18: Remove the rear lamp assemblies.
- Step 19: Position the rear bumper cover aside for access to electrical connector.
  - 1. Release the sides of the rear bumper cover from the brackets.
  - 2. Release the center of the rear bumper cover from the rear brackets and position aside.



Step 20: Disconnect the rear bumper wiring harness electrical connector.





NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS © Ford Motor Company 2020

#### Step 21: Remove the rear bumper cover.



0100956

#### Step 22: NOTE: On both sides.

Inspect the side bracket for damage.




Ford Factory Shop Manual purchase options <u>www.motorcraftservice.com</u>

Techline 1-800-367-378 Page 13 of 18 IS M-5200-M4xxBV 031020



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS © Ford Motor Company 2020

#### Step 23: Inspect the rear brackets for damage.



Step 24: If required, remove the screws and the side bracket.


*Torque*: 13 lb.in (1.5 Nm)

If required, remove the screws and the outer rear bracket.

*Torque*: 13 lb.in (1.5 Nm)

If required, remove the screws and the center rear bracket.

*Torque*: 13 lb.in (1.5 Nm)



Side Outer Rear Center Rear



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS © Ford Motor Company 2020

Step 25: Cut rear bumper cover as marked. (Both sides)



Step 26: Install lower valance by snapping into place and installing 3 screws on each side.





NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS © Ford Motor Company 2020

Step 27: Transfer any other hardware from removed bumper cover, if not already installed on bumper cover.





#### **Rear Bumper Cover Installation**

To install, reverse the removal procedure.

Step 13: Install supplied clamps onto new muffler, slide muffler hangers into factory exhaust hangers. Next slide the muffler over the under axle pipes, center muffler in rear bumper opening and tighten clamps to 48 nm (35 lb-ft)



Ford Factory Shop Manual purchase options www.motorcraftservice.com

Techline 1-800-367-378 Page 16 of 18 IS M-5200-M4xxBV 031020



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS  $\circledcirc$  Ford Motor Company 2020

Ford Factory Shop Manual purchase options <u>www.motorcraftservice.com</u>

Techline 1-800-367-378 Page 17 of 18 IS M-5200-M4xxBV 031020



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS © Ford Motor Company 2020

Step 14: Check all fasteners for proper torque.

Step 15: Check alignment of mufflers in rear bumper cover.



Step 16: Lower vehicle and road test.

**END**