


Installation points  
Focus ST Lower Sport Spoiler  
2363-CS-AA

- To ensure good tape adhesion, make sure the top of the center section of the lower bumper (red arrows below) is clean and free of wax and grime before installation.



- BEFORE removing the backing on the double sided tape, test fit the mountune Lower Sport Spoiler making sure it is flush and meets the existing bumper at both ends. On rare occasion, the top slots may require a small amount of material removal to obtain a perfect fit. Please note that prior damage to the existing bumper may prevent correct fitment of the mountune Lower Sport Spoiler.
- Once it has been determined the spoiler will fit correctly, remove the backing on the double sided tape and fit the spoiler in place. Press firmly down on the top section to ensure the double sided tape is adhering to the bumper.



**Remove blue double sided tape backing.**

- Secure the mountune Lower Sport Spoiler in place using the two provided self-tapping screws. Insert the screws in the existing holes in the Sport Spoiler and turn clockwise until the screw is firmly seated. DO NOT over tighten the screws.
- The mountune Lower Sport Spoiler is painted using Automotive Grade paint and can be treated like typical automotive finishes.