

NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS

PRIOR TO INSTALLATION READ THESE INSTRUCTION COMPLETELY For questions, Call the FORD PERFORMANCE Techline 1-800-367-3788

Please visit https://www.performanceparts.ford.com for warranty information



Kit Contents	Quantity
Fog Lamp Assembly	2
Wiring Harness	1



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS

INSTALLATION PROCEDURE

NOTE: Right-hand side shown, left-side similar.

1. Remove the front bumper trim panel. Do NOT discard pushpins. See Figure 1.

NOTE: If vehicle is equipped with an accessory that will not allow for removal, this part can be positioned aside.




FIGURE 1

2. Remove the front bumper end cap. See Figure 2. Do NOT discard hardware.




FIGURE 2



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS

3. Install new fog light assembly, reusing the hardware from the previous step. See Figure 3. Torque: 18 lb.ft (25 Nm)




FIGURE 3

4. Reinstall the front bumper trim panel, reusing the hardware from Step 1. See Figure 4.




FIGURE 4



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS

- 5. Repeat steps 1-4 to install fog light assembly to the left side of the vehicle.
- 6. Connect the included wire harness to the back of both fog lights. See Figure 5.




FIGURE 5

7. Remove the fastener and the air intake duct. Do NOT discard fastener. See Figure 6.




FIGURE 6



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS

8. Remove the pushpins and the radiator upper shield. Do NOT discard pushpins. See Figure 7.




FIGURE 7

9. Route harness up through the front bumper, behind the grill. See Figure 8.




FIGURE 8



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS

10. Continue routing wire harness through engine bay as shown in Figure 9, moving towards the auxiliary switch wiring.




FIGURE 9

11. Locate an on-vehicle ground near the auxiliary switch wire ends and ground the wire harness. See Figure 10.

NOTE: When grounding harness, use a crimp-on ring terminal and heat shrink.




FIGURE 10



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS

12. Secure the wires to the desired auxiliary switches. If one switch is desired to operate both fog lights, auxiliary switches 1, 2 or 3 can be used. If two switches are desired to operate the fog lights any of the switches can be used. Both wires can NOT be secured to Auxiliary switches 4, 5 or 6. See Figure 11.

Auxiliary Switch Wire Colors:

AUX1 - Green with Blue tracer (GN-BU)

AUX2 - Grey with Brown tracer (GY-BN)

AUX3 - White with Violet tracer (WH-VT)

AUX4 - White with Blue tracer (WH-BU)

AUX5 - Blue with Brown tracer (BU-BN)

AUX6 - Violet with Orange tracer (VT-OG)




FIGURE 11



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS

13. Secure chosen wire connection(s) with solder and dual-walled heat shrink. See Figure 12.

NOTE: Gently squeeze the ends of the heat shrink tubing sleeve (while heat shrink is still warm) to ensure a tight fit and close any air gaps.




FIGURE 12

14. Install the pushpins and the radiator upper shield. See Figure 13.




FIGURE 13



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS

15. Install the fastener and the air intake duct. See Figure 14.




FIGURE 14