



<u>LABEL</u>	<u>CONTAINS</u>	<u>SWITCH TYPE</u>
Ignition Switch (12V Key On)	Cavity 1, YE Cavity 2, RD/LG	SPST (2 Terminals)
Fuel Pump Switch	Cavity 3, RD/LG Cavity 4, TN/LB	SPDT (3 Terminals)
Ignition Lamp	Cavity 7, BK Cavity 8, RD/LG	SPST (2 Terminals)
Aux 1, 12V HAAT	Cavity 9, YE	Female Spade
Aux 2, 12V Key On	Cavity 10, RD	Female Spade
Aux 3, 12V Key On	Cavity 10, RD	Female Spade