


NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS

Please visit www.performanceparts.ford.com for the most current instruction and warranty information.

PLEASE READ ALL OF THE FOLLOWING INSTRUCTIONS CAREFULLY PRIOR TO INSTALLATION. AT ANY TIME YOU DO NOT UNDERSTAND THE INSTRUCTIONS, PLEASE CALL THE FORD PERFORMANCE TECHLINE AT 1-800-367-3788



NOTICE: Do not spill brake fluid on painted or plastic surfaces or damage to the surface may occur. If brake fluid is spilled onto a painted or plastic surface, immediately wash the surface with water.

Factory Ford shop manuals are available from Helm Publications, 1-800-782-4356



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS

INSTALLATION

- **STEP 1:** Raise and support the vehicle to gain access to the undercarriage.
- **STEP 2:** Remove (1) bolt that supports the intake tube to the driver side frame rail if equipped.





STEP 3: Remove the intake tube from the fire wall by gently pulling towards the front of vehicle, then place to the side.





Factory Ford shop manuals are available from Helm Publications, 1-800-782-4356

Techline 1-800-367-3788

Page 2 of 9



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS

STEP 4:

Place a clean towel under the hydraulic clutch line to catch any fluid during the removal process.



STEP 5: Using a small pick, gently pull the hydraulic hose retaining clip outboard to release the hose.





STEP 6:

Gently pull the hydraulic hose out of the clutch cylinder housing.





Factory Ford shop manuals are available from Helm Publications, 1-800-782-4356

Techline 1-800-367-3788

Page 3 of 9



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS

STEP 7: Locate the lower hydraulic hose connection from the underside of vehicle on the driver side of the transmission. Using a small pick, gently pull the hydraulic hose retaining clip outboard to release the hose.





STEP 8: Gently pull the hydraulic hose out of the transmission elbow.



STEP 9: From the topside of the vehicle, carefully feed the hydraulic clutch line out of the vehicle.



Factory Ford shop manuals are available from Helm Publications, 1-800-782-4356

Techline 1-800-367-3788



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS

STEP 10: Feed the new hydraulic clutch line under the brake booster and down along the side of the transmission housing. Correct orientation will have the solid portion of the line at the top side of vehicle with the flexible steel braiding next to the transmission housing.



Factory Ford shop manuals are available from Helm Publications, 1-800-782-4356

Techline 1-800-367-3788

Page 5 of 9



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS



STEP 11: Push the hydraulic hose retaining clip back into the housing.



Factory Ford shop manuals are available from Helm Publications, 1-800-782-4356

Techline 1-800-367-3788

Page 6 of 9



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS

STEP 11: Lubricate the O-ring and gently push the new hydraulic clutch line end into the clutch cylinder housing until it locks into the retaining clip.



STEP 12: From the underside of the vehicle, push the hydraulic hose retaining clip back into the elbow.



STEP 13: Feed the new hydraulic clutch line down the elbow on the transmission housing, lubricate the O-ring and gently push the new hydraulic clutch line end into the clutch cylinder housing until it locks into the retaining clip





Factory Ford shop manuals are available from Helm Publications, 1-800-782-4356



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS

STEP 14: Reinstall the intake tube into the fire wall by gently pushing into its location if equipped.



STEP 15: Install (1) bolt that supports the intake tube to the driver side frame rail.



- **STEP 16:** Using Motorcraft High Performance DOT 3 Motor Vehicle Brake Fluid, follow the procedure below to bleed the hydraulic system of air.
- **STEP 17:** Make sure the clutch pedal is in the most upward position.
- **STEP 18:** Check the fluid level of the brake/clutch reservoir. Fill the reservoir with the specified fluid to the MAX mark.
- **STEP 19:** Using a suitable bleeder kit and a vacuum pump, install the rubber stopper in the reservoir opening. Make sure the rubber stopper has a tight fit.

Factory Ford shop manuals are available from Helm Publications, 1-800-782-4356



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS



- **STEP 20:** Holding the rubber stopper in place, operate the vacuum pump to 15-20 inches of vacuum. Hold the vacuum for 1 minute, then quickly relieve the vacuum. Remove the special tools.
- **STEP 21:** Check the fluid level of the reservoir. Fill the reservoir with the specified fluid to the MAX mark. Install the reservoir cap.
- **STEP 22:** Depress and release the clutch pedal 10 to 12 times or until clutch pedal effort is consistent and positive at top of clutch pedal travel.
- **STEP 23:** Repeat Steps 20, 21 and 22 two additional times or until clutch pedal effort is consistent and positive at top of clutch pedal travel.
- **STEP 24:** Check the fluid level of the reservoir. Add fluid as necessary. Test the clutch system for normal operation.

Factory Ford shop manuals are available from Helm Publications, 1-800-782-4356